

Transparency Unit

B813021/B813022

GT80FLU

for EPSON image scanner

GT-6500

GT-8000

ES-600C

English

Deutsch

Français

Español

Italian

日本語

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein.

While every precaution has been taken in the preparation of this manual, Seiko Epson Corporation assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchase of this products or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the US) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be held liable against any damage or problems arising from the use of any options other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Epson is a registered trademark of Seiko Epson Corporation.

Copyright © 1992 by Seiko Epson Corporation, Nagano, Japan

EPSON



Transparency Unit


for use with EPSON Scanners

B813021/B813022


This transparency unit is a high-quality device developed to enable Epson Scanner owners to scan transparencies and slides. By installing this unit on your Epson scanner, you can scan transparencies and slides beautifully, in full color. Also, it is not necessary to remove this unit if you wish to return to scanning normal reflective (paper) documents.

Unpacking the Unit


When you first open the package, make sure that all the following items are included and that none has been damaged during shipping. Contact your Epson dealer if any item is missing or damaged.




Transparency Unit




User's Guide



Reflective Document Mat



Screws (2)





Transparency Document Guide



Removing the Shipping Screw

To prevent damage during shipping a shipping screw is attached to the transparency unit. Make sure this screw is removed according to the following steps before you attempt to use this unit.

1. Turn the unit so the glass side faces up.
2. Remove the screw from the position shown below.



3. Insert the screw you just removed into the storage-hole in the position shown.




- Note:** . Keep the shipping screw in a safe place; you will need it if you should need to transport the scanner. When transporting the scanner, you should remove the transparency unit and reattach the shipping screw.
- If the unit's lamp assembly is not in its initial position, you cannot attach the shipping screw. If this happens, reattach the unit to the scanner, close the unit, and turn the scanner on; the unit's lamp assembly then returns to its initial position. Then turn off the scanner and remove the transparency unit.


Installing the Transparency Unit on the Scanner

Follow the steps below to install the transparency unit on the scanner.

1. Make sure the scanner's power switch is turned off and remove the power cable from the scanner.
2. Remove the document cover from the scanner.
3. The scanner comes with two mounting screws attached; slide the mounting slots on the transparency unit forward underneath these two screws.




4. Use a coin to tighten the two screws and secure the transparency unit.




5. Close the transparency unit.

6. Connect the transparency unit's connector to the option connector on the scanner.



Transparency Document Guide and Reflective Document Mat

A transparency document guide and reflective document mat are included with this unit. Use as necessary.



Positioning Transparencies

You can scan the transparency types shown below:


Document type Transparency documents (including slide film) in color or monochrome

Scanning size Up to 5 x 5 inches (127 x 127 mm)

- Note:**
- Wipe the glass of the transparency unit, the scanner's document table, and the narrow window near the mounting bracket before scanning transparencies.
 - Your scanner software automatically handles the operation of the transparency unit.

Position transparency documents according to the steps below.

1. Open the transparency unit.
2. Place the transparency document guide on the scanner's document table.
3. Using the transparency document guide, place the transparency document face down on the scanner's glass document table. Align the transparency document with the upper right-hand corner of the transparency document guide.



4. Close the unit. If the reflective document mat is in place, remove it from the transparency unit.


Note: Make sure the unit is completely closed. If it is not closed, an option error results and you cannot scan the document.

Scanning Normal (Reflective) Documents


When you return to scanning normal reflective documents, you should always insert the reflective document mat included with this unit. Also, make sure you remove the transparency document guide from the scanner's document table.

Insert the reflective document mat as described below.

1. Open the transparency unit.
2. Insert the reflective document mat.



3. Position the reflective document and close the unit.



To remove the reflective document mat, lift up on the mat and pull it out of the transparency unit.

EPSON OVERSEAS MARKETING LOCATIONS

EPSON AMERICA, INC.

20770 Madrona Ave.

P.O. Box 2842

Torrance, CA 90509-2842

Phone: (800) 922-8911

Fax: (310) 782-5220

EPSON UK LTD.Campus 100, **Maylands Avenue.**Hemel Hempstead, **Herts,**

HP2 7E2, U.K.

Phone: 442-61144

Telex: 5182467

EPSON DEUTSCHLAND GmbH

Zülpicher Straße 6,

4000 Dusseldorf 11 F.R. Germany

Phone: (02 11) 56030

Telex: 8584786

EPSON FRANCE S.A.

68 bis, rue Marjolin

92300, Levallois-Perret, France

Phone: (1) 4087-3737

Telex: 6 10657

EPSON AUSTRALIA PTY. LTD.

Unit 3, 17 Rodborough Road,

Frenchs Forest, NSW 2086, Australia

Phone: (2) 452-0666

Fax: (2) 975-1409

EPSON SINGAPORE PTE. LTD.No. 1 Raffles **Place #26-00**

OUB Centre, Singapore 0104

Phone: 5330477

Fax: 5338119

EPSON HONG KONG LTD.

25/F, Harbour Centre.

25 Harbour Road, Wanchai,

Hong Kong

Phone: 5854600

Telex: 65542

**EPSON ELECTRONICS TRADING LTD.
(TAIWAN BRANCH)**10F. No. 287 Nanking **E. Road, Sec. 3,**

Taipei, Taiwan, R.O.C.

Phone: (02) 7 17-7360

Fax: (02) 712-9164

EPSON ITALIA S.p.A.

V.le F.lli Casiraghi 427

20099 Sesto S. Giovanni

MI, Italy

Phone: 2-26233 1

Fax: 2-2440750

EPSON IBERICA S.A.

Av. de Roma, 18-26

08290 Cerdanyola del Valles

Barcelona, **Spain**

Phone: 582.15.00

Fax: 582.15.55

**SEIKO EPSON CORPORATION
(Hirooka Office)**

80 Harashinden, Hirooka

Shiojiri-shr, Nagano-ken

399-07 Japan

Phone: (0263) 52-2552